

### Elegant Bedside Table, Parts and Cut List

	Quant	Part	Dimensions	Notes & Resources
A	4	Legs	1-1/2" x 1-1/2" x 26"	Taper results in 3/4" foot. Originates 6" from top end
B	2	Side rails	3/4" x 5-1/2" x 11-1/2"	Cut 1/2" long tenons on each end. Make mortises 5" long, 9/16" deep, 1/2" on center from face of leg.
C	1	Back rail	3/4" x 5-1/2" x 14"	Cut 1/2" long tenons on each end. Make mortises 5" long, 9/16" deep, 1/2" on center from face of leg.
D	2	Front rails	3/4" x 1-1/4" x 14"	Cut 1/2" long tenons on each end. Make mortises 3/4" long, 9/16" deep, 1/2" on center from face of leg.
E	2	Drawer rails	3/4" x 1-1/4" x 11-3/4"	Cut to fit after assembly
F	2	Fillers	5/8" x 2" x 10-1/2"	Plane to fit from inside face of rail to inside face of leg
G	1	Drawer kicker	3/4" x 1-1/4" x 11-3/4"	Cut to fit after assembly
H	1	Top/field	3/4" x 14-1/2" x 14-3/4"	Length allows for 3/8" tongues
I	2	Breadboard ends	3/4" x 2" x 14-1/2"	
J	1	Drawer front	5/8" x 2-7/8" x 12-7/8"	
K	2	Drawer sides	5/8" x 2-7/8" x 12-1/4"	Cut to length depending on your joinery
L	1	Drawer back	5/8" x 2-3/8" x 12-1/4"	Cut to width and length depending on your joinery
M	1	Drawer bottom	1/4" x 12-3/16" x 12-1/8"	
	4	Tabletop fasteners	Part #34215	Rockler (800) 279-4441 www.rockler.com
	1	Toggle clamp	Part #20787	Rockler (800) 279-4441 www.rockler.com

### Elegant Bedside Table Notes

- Tenons are 1/4" thick, 1/2" long
- Mortises are router cut, so are round on the ends. Square corners on tenons are pared to fit round ends on mortises.
- Drawer kicker has one screw pocket in each end. 1" screw pocket screws into center of front and back rails.
- Saw kerf for table top fasteners 3/8" down from top edge, 1/4" deep, side rails only.
- 1/8" reveal between outside faces of rails and outside faces of legs