



CLASS RESOURCE

KNOW YOUR 120-VOLT ELECTRICAL SYSTEM

Common Amperage Draw

The table below provides you with the approximate 120-Volt Amperage (amp) Draw for each of these common RV appliances.

APPLIANCE	AVERAGE DRAW
Air Conditioner (Pre 1990)	18 amps (at full capacity)
Air Conditioner (Post 1990)	14 amps (at full capacity)
Converter/Battery Charger	6-9 amps
Blender	5.5 amps
Ceramic Floor Heater	12-14 amps
Coffee Pot (Percolator)	8 amps
Coffee Pot (Single Serve Cup)	10-14 amps
Computer	.5 amps
Curling Iron	.7 amps
Electric Blanket	2 amps
Hair Dryer (1500 watts)	13 amps
Hair Dryer (400 watts)	3.5 amps
Iron	6-10 amps
Microwave	8 amps
Microwave/Convection	13 amps
Refrigerator	3.5 amps
Television	.5-1 amp
Toaster	10 amps
VCR/DVD Player	.5 amps
Washer/Dryer	13 amps
Water Heater (Electric 10 ga)	12 amps