




Short Upper stretcher (long tenon) 1/2" x 1/2" x 3-3/8"




Short Lower stretcher (short tenon) 1/2" x 3/4" x 2-7/8" (cut at 3-3/8")




Long Upper stretcher (short tenon) 1/2" x 1/2" x 8" (cut at 9-1/4")



Long Lower stretcher (2 needed). 1/2" x 3/4" x 9-1/4"









Note: these two dimensions may be different after dry assembly verification. Be sure to check before cutting.



Note: red dimensions refer to center points, black dimensions refer to the mortise cut dimensions.


Bottom of leg

Bottom of leg




These are the guidelines for setting up the green and red regions on page 3. Start with the 1/8" spacer between the stop and the leg bottom and leave it in place. Once done, than continue to the red region, rotate the leg to the proper face, and drill first with the 1/4" spacer between the stop and the bottom of the leg. Than remove the spacer and drill again. Continue until done.


Place a 1/8" spacer between the stop and the leg bottom and leave it in place. Now drill the first green mortise, then the second.



When ready to start the red group, rotate the leg to the appropriate face, place the 1/4" spacer and drill the first hole of the through mortise.



Finally, remove the 1/4" spacer and drill the second hole of the through mortise.



Initial Cuts

Some of the dimensions below are the required dimension. Others are overcut so you have enough wood milled to the proper size and ready to go for final cut. You may also want to have extra cut so that you have extra ready to go if needed.

